


FUEL SYSTEM OPERATIONS

NOTE: Where fuel system equipment has emission control features, refer to Division 17 of this Manual.

Accelerator throttle controls arrangements	19.00.00
Air cleaner	
— remove and refit	19.10.04
— clean and refill	19.10.16
Carburettor	
— remove and refit	19.15.09
— overhaul and adjust	19.15.17
Cold start control cable	
— remove and refit	19.20.26
Fuel lift pump	
— remove and refit	19.45.09
— overhaul	19.45.16
Fuel filters	Refer to Maintenance Division 10
Fuel tank	
— remove and refit	19.55.01
Fuel tank gauge unit	Refer to Division 88 (Controls)
Throttle linkage	
— remove and refit	19.20.07





Accelerator levers and rods.



Key to illustration of accelerator levers and rods.

- | | | |
|---|---|--|
| 1. Bracket for accelerator pedal and stop | | |
| 2. Bolt (1/4in. UNF x 1/2in. long) | } Fixing bracket and pedal stop to dash | |
| 3. Spring washer | | |
| 4. Nut (1/4in. UNF) | | |
| 5. Pedal stop lever | | |
| 6. Bolt (1/4in. UNF x 1 1/4in. long) | } Fixing lever to pedal shaft | |
| 7. Plain washer | | |
| 8. Nut (1/4in. UNF) | | |
| 9. Accelerator pedal | | |
| 10. Bolt (5/16 in. UNF x 5/8 in. long) | } Fixing pedal to shaft | |
| 11. Nut (5/16 in. UNF) | | |
| 12. Bolt (5/16 in. UNF x 1 1/8 in. long) | } Pedal stop in floor | |
| 13. Plain Washer | | |
| 14. Nut (5/16 in. UNF) | | |
| 15. Bracket for accelerator pedal shaft | | |
| 16. Bolt (1/4in. UNF x 5/8 in. long) | } Fixing bracket to dash | |
| 17. Plain washer | | |
| 18. Spring washer | | |
| 19. Nut (1/4in. UNF) | | |
| 20. Shaft for accelerator pedal | | |
| 21. Special washer | } On accelerator shaft | |
| 22. Plain washer | | |
| 23. Lever assembly for accelerator | | |
| 24. Ball end for lever | | |
| 25. Bolt (1/4in. UNF x 1 1/4in. long) | } Fixing lever to shaft | |
| 26. Plain washer | | |
| 27. Nut (1/4in. UNF) | | |
| 28. Mounting bracket for extension shaft | | |
| 29. Bearing in mounting bracket for shaft | | |
| 30. Extension shaft and lever | | |
| | | 31. Ball end for extension shaft lever |
| | | 32. Spring washer |
| | | 33. Nut (2 BA) |
| | | 34. Plain washer |
| | | 35. Conical spring for extension shaft |
| | | 36. Control rod, pedal shaft to extension shaft |
| | | 37. Ball joint socket for control rod |
| | | 38. Locknut (2 BA) fixing socket to control rod |
| | | 39. Return spring, bell crank to extension shaft |
| | | 40. Bracket assembly for accelerator cross-shaft |
| | | 41. Bearing for cross-shaft |
| | | 42. Accelerator cross-shaft and lever |
| | | 43. Spiral pin for cross-shaft |
| | | 44. Boss for cross-shaft |
| | | 45. Spring dowel fixing boss to shaft |
| | | 46. Bell crank lever and bearings assembly |
| | | 47. Bearing for bell crank |
| | | 48. Support bracket for bell crank |
| | | 49. Set bolt (1/4in. UNC x 5/16 in. long) |
| | | 50. Spring washer |
| | | 51. Centre pin |
| | | 52. Spring washer |
| | | 53. Nut (5/16 in. UNC) |
| | | 54. Control rod, cross-shaft to bell crank |
| | | 55. Spring washer |
| | | 56. Nut (10 UNF) |
| | | 57. Control rod, bell crank to carburettor |
| | | 58. Ball joint |
| | | 59. Locknut (2 BA) |
| | | 60. Ball end |
| | | 61. Spring washer |
| | | 62. Nut (2 BA) |



AIR CLEANER

— Remove and refit

19.10.04


Removing

1. Lift and prop the bonnet.
2. Disconnect the air intake hose from the carburettor inlet.
3. Slacken the fixings and move aside the retaining strap.
4. Remove the air cleaner complete with hose.

NOTE: Be sure to keep air cleaner level otherwise oil may spill.

Refitting

5. Reverse 1 to 4. Ensure that the oil container hinged clips are clear of the retaining strap supports when fitted.



AIR CLEANER

—Clean and refill


19.10.16

Dismantling

1. Remove the air cleaner. 19.10.04.
2. Release the hinged clips.
3. Withdraw the oil container.
4. Withdraw the sealing washer.
5. Lift out the wire mesh element.
6. Drain the oil container.
7. Remove the air intake cap.
8. Wash the metal parts in clean fuel.

Assembling

9. Add clean engine oil to the oil container (Division 09 refers), fill to the oil level mark.
10. Reverse 1 to 5 and 7, using a new sealing washer.



FUEL SYSTEM


CARBURETTOR, Zenith type 175 CD2S

—Remove and refit

19.15.09


Removing

1. Disconnect the top cover breather hose at the carburettor elbow.
2. Release the air cleaner retainer strap.
3. Withdraw the air cleaner complete with hose, carburettor elbow and joint washer.
4. Disconnect the distributor vacuum pipe.
5. Release the cold start control inner cable.
6. Withdraw the cold start outer cable from the spring clip.
7. Disconnect the crankcase breather hose.
8. Disconnect the fuel inlet pipe.
9. Disconnect the accelerator linkage.
10. Remove the fixings and withdraw the carburettor.
11. Withdraw the carburettor adaptor and joint washer.



Refitting

12. Reverse 1 to 10. When the cold start cable is connected, ensure that full travel on the carburettor linkage is obtainable in both directions.




IRC 1057



CARBURETTOR, Zenith type 175CD 2S**—Overhaul and adjust****19.15.17****Service tool: S353****Dismantling**


1. Remove carburettor. 19.15.09.
2. Remove damper.
3. Remove bottom plug.
4. Drain carburettor of oil and fuel.
5. Remove 'O' ring from plug.
6. Remove six screws securing float-chamber to body.
7. Remove float-chamber.
8. Remove float assembly by gently prising spindle from clip each end.
9. Remove needle valve.
10. Remove four screws securing top cover to body.
11. Remove top cover.
12. Remove spring.
13. Remove air valve assembly.
14. Remove four screws securing diaphragm and retaining ring to air valve assembly.
15. Remove diaphragm and retaining ring.
16. Slacken grub screw in side of air valve.
17. Insert tool S353 in stem of air valve, turn anti-clockwise approximately two turns, withdraw needle and housing by pulling firmly and straight with the fingers.
18. Remove two screws securing starter box to body.
19. Remove starter box.
20. Remove two screws securing butterfly to spindle.
21. Turn spindle, remove butterfly.
22. Release spindle return spring.
23. Withdraw spindle and spring.
24. Remove spindle seals from body by hooking out with small screwdriver.
25. Wash all components in clean fuel, allow to drain dry or use clean compressed air. Place all components on a clean surface. Discard all seals and gaskets.
26. Examine the condition of all components for wear, paying special attention to needle and seat, air valve and diaphragm which should be renewed unless in exceptionally good condition.
27. Use clean compressed air to blow through all ports, needle valve and starter box.

*Continued*

FUEL SYSTEM


Reassembling

- 28. Fit spindle seals to body, tapping gently into position, with metal casing of seals flush with body of carburettor.
- 29. Insert spindle, loading and locating spindle return spring whilst so doing.
- 30. Insert butterfly with two protruding spots, outboard and below spindle, tighten screws.




- 31. Fit starter box, tighten screws.
- 32. Insert needle housing assembly into the bottom of the air valve.
- 33. Fit tool S353, turning clockwise to engage threads of needle valve assembly with adjusting screw; continue turning until slot in needle housing is aligned with grub screw.
- 34. Tighten grub screw.

NOTE: The grub screw does not tighten on the needle housing but locates into the slot. This ensures that, during adjustment, the needle will remain in its operating position, i.e. biased, by a spring in the needle housing, towards the air cleaner side of the carburettor.



- 35. Fit diaphragm, locating inner tag into recess in air valve.
- 36. Fit diaphragm retaining ring; secure with four screws.
- 37. Fit air valve assembly, locating outer tag and rim of diaphragm in complementary recesses in carburettor body.
- 38. Fit carburettor top cover with bulge on housing neck towards air intake.
- 39. Fit and evenly tighten top cover screws.




Continued



40. Fit needle valve and sealing washers; tighten.
41. Fit float assembly by levering pivot pin gently into position.
42. Check float height by measuring the distance between the carburettor gasket face and the highest point of the floats.

****NOTE:** The float heights must be equal and set to 16 to 17 mm (0.629 to 0.669 in). Adjust by bending tabs ensuring that tab sits on needle valve at right angles. **

43. Fit float-chamber gasket.
44. Fit float-chamber, secure with six screws.
45. Fit 'O' ring to bottom plug.
46. Fit bottom plug.




47. Fit carburettor. 19.15.09.
48. Fill carburettor damper dashpot with the correct grade of engine oil to within 6 mm (0.250 in) of the top of the air valve shaft.
49. Fit damper.
50. Tune carburettor.



Zenith type 175 CD 2S

Fast idle adjustment, carburettor removed

51. Set the cold start adjuster fully outward.
52. Slacken the fast idle adjusting screw.
53. Hold the cold start cam lever in the maximum position.
54. Adjust the fast idle adjusting screw against the cam lever to obtain a 1,0 to 1,1 mm (0.039 to 0.043 in) clearance between the top edge of the throttle butterfly and the carburettor barrel wall.
55. Measure the clearance using feeler gauges or a 1,1 mm (No. 57) diameter drill shank.
56. Secure the fast idle adjusting screw locknut without disturbing the adjustment.
57. Refit the carburettor 19.15.09.




IRC 1079

Fast-idle adjustment, carburettor fitted

58. Operate fully the cold start control
59. Adjust the fast-idle stop screw to obtain an engine speed of 1,000 to 1,200 rev./min.
60. Return the cold start control and ensure that the fast-idle stop screw is clear of the cam lever.

Low temperature starting

61. For starting at temperatures down to -18°C (0°F) push and turn the spring-loaded choke adjustment screw so that the peg is at right-angles to the slot as illustrated. Leave in this position. When starting at temperatures below -18°C (0°F) turn the screw until peg is recessed in slot.





IRA 47C



Zenith type 175 CD 2S

Mixture check and adjust

62. Run the engine until normal operating temperature is obtained. If necessary adjust slow-run screw to give the correct idling speed.
63. Lift the carburettor piston approximately 0.8 mm (0.031 in) and note the engine response as follows:
NOTE: Remove air cleaner inlet elbow from carburettor to gain access to piston.
 - (a) Engine speed increases immediately Rich mixture
 - (b) Engine speed decreases or stalls Weak mixture
 - (c) Engine speed increases slightly then returns to normal, Correct mixture
64. Should the mixture require adjustment, remove carburettor damper and carefully insert special tool S353 into the hollow piston guide rod so that the inner part of the tool engages in a female hexagon in the needle adjusting screw.
Hold the outer part of the tool firmly and turn the inner tool clockwise to enrich or anti-clockwise to weaken mixture.
65. Check mixture as instruction 63.
66. Adjust if necessary.
67. Top up damper dashpot and replace damper.
68. Finally reconnect air cleaner and adjust the slow-run screw to obtain a smooth idling speed of approximately 650 rev./min.
69. The fast idle screw should not require adjustment.



DATA

Float height
Fast-idle setting, carburettor removed

Fast-idle setting, carburettor fitted
Idling speed

16 to 17 mm (0.629 to 0.669 in)
1,0 to 1,1 mm (0.039 to 0.043 in) clearance between throttle butterfly top edge and carburettor barrel.
1000 to 1,200 rev./min.
650 rev./min.



FUEL SYSTEM

FLOAT-CHAMBER NEEDLE VALVE

—Remove and refit 19.15.24

Removing

1. Remove carburettor. 19.15.09.
2. Remove six screws securing float-chamber to body.
3. Remove float-chamber.
4. Remove gasket.
5. Remove float assembly by gently prising spindle from clip each end.
6. Remove needle valve.

Refitting

1. Reverse 1 to 6—renew gasket.

FLOAT-CHAMBER LEVEL

—Check and adjust 19.15.32

1. Remove carburettor. 19.15.09.
 2. Remove six screws securing float-chamber to body.
 3. Remove float-chamber.
 4. Remove gasket.
 5. Check distance between gasket face on carburettor body to highest point of each float.
- NOTE:** The height of each float must be equal and correct to datum setting which is 16 to 17 mm (0.629 to 0.669 in).

To adjust

6. Bend tab over to obtain correct setting ensuring that the tab sits on needle valve at right angles.
7. Fit new gasket, reverse 1 to 3.

DIAPHRAGM




→Remove and refit 19.15.35

Removing

1. Remove four screws securing top cover to carburettor body.
2. Lift off top cover.
3. Remove spring.
4. Remove diaphragm retaining plate (four screws).
5. Remove diaphragm.

Refitting

6. Fit diaphragm, locating inner tag in air valve recess.
7. Fit retaining plate, ensure correct diaphragm seating, tighten screws.
8. Locate diaphragm outer tag in recess in carburettor body, and rim bead in annular groove.
9. Fit top cover, evenly tighten securing screws.



THROTTLE LINKAGE

—Remove and refit

19.20.07

General

The following instructions are generally applicable but reference should be made to the exploded views and descriptions of accelerator controls for detail variations, refer to 19.00.00.

NOTE: Access to the throttle linkage at the rear of the engine is best obtained by removing the gearbox tunnel cover. 76.25.07.

Removing

1. Disconnect the linkage return springs.
2. Disconnect the linkage adjacent to the pedal box.
3. Disconnect the linkage at the carburettor or fuel distributor pump.
4. Remove the RH retaining bracket from the engine compartment dash.
5. Withdraw the throttle linkage complete.

Refitting

6. Reverse 1 to 6 leaving the pinch bolts loose at this stage.
7. Depress the throttle pedal onto the stop on the toe box floor.
8. Hold the throttle linkage in the fully open position.
9. Tighten the linkage pinch bolts and release the pedal and linkage.
10. If necessary adjust the throttle pedal stop on the toe box floor and the return stop at the toe box to permit full and unrestricted throttle opening.

Issue 1. Dec. 77

19.15.50
19.20.07

COLD START CONTROL CABLE

—Remove and refit


19.20.26

Removing


1. Disconnect the battery earth lead.
2. Disconnect the inner and outer control cables at the carburettor.
3. Slacken the locknut and release the retainer screw fixing the switch unit to the control cable.
4. Disconnect the white/blue lead from the front connector blade and the black lead from the rear blade.
5. Withdraw the switch unit.
6. Withdraw the cable grommet at the engine compartment dash.
7. Remove the fixings and withdraw the steering column switch shrouds to gain access to the control cable.
8. Remove the locknut and shakeproof washer fixing the outer cable to the mounting bracket.
9. Push the control forward to clear the hole in the mounting bracket.
10. Lift the control and pass the inner cable through the slot provided in the bracket.
11. Withdraw the control cable assembly complete.

Refitting

12. Reverse 1 to 11; ensure that the control knob is fully forward and the choke mechanism is fully open before clamping the inner cable at the carburettor.



2RC 37



2RC 38

FUEL LIFT PUMP

— Remove and refit


19.45.09

Removing

1. Disconnect the battery leads.
2. Lift the seat (RH side) and remove the seat box panel to expose the fuel pump.
3. Disconnect the wiring at the 'Lucar' connectors.
4. Disconnect the fuel outlet pipe.
5. Disconnect the fuel inlet pipe.
6. Remove the clamp fixings.
7. Withdraw the pump and mounting rubbers.

Refitting

8. Reverse 1 to 7.



FUEL LIFT PUMP


—Overhaul

19.45.16

The fuel pump is not repairable or serviceable, repair is by replacement. The only servicing required is to replace the fuel filter element every 20.000 km (12,000 miles) or 12 months.

Proceed as follows:

1. Remove pump 19.45.09
2. Remove base from fuel pump.
3. Remove and discard filter element.
4. Reassemble pump with new element.
5. Refit pump and reconnect.



FUEL TANK, side mounted

—Remove and refit


19.55.01

Removing

1. Disconnect the battery earth lead.
2. Drain fuel into a clean container.
3. Remove RH seat cushion and fold seat squab forward.
4. Disconnect hoses, tank to filler tube and breather hose.
5. Remove cover panel for fuel tank.
6. Disconnect wires at gauge unit.
7. Disconnect fuel supply pipe.
8. Support tank and remove tank securing bolts.
9. Lower tank and remove from under the vehicle.

Refitting

10. Reverse 1 to 9.

**FUEL EXPANSION TANK**


—Remove and refit

Removing

1. Expansion tank located LH rear wheel arch, forward section.
2. Disconnect fuel lines.
3. Remove tank securing bolts.
4. Remove tank.

Refitting

5. Reverse 2 to 4.



Issue 1. Dec. 77

19.55.01
A19.55.11

