

REAR SUSPENSION OPERATIONS

NOTE: The procedures for Rear Suspension items are similar to those for the Front Suspension items, therefore refer to Division 60 for particulars. For reference, the applicable Front Suspension operation number is listed below in parentheses after the Rear Suspension operation number.

Rear hub assembly										
— remove and refit	64.15.01 (60.25.01)
— overhaul	64.15.07 (60.25.07)
Rear hub bearing end-float										
— check and adjust	64.15.13 (60.25.13)
Rear hub stub axle										
— remove and refit	64.15.20 (60.25.22)
— overhaul	64.15.21 (60.25.24)
Rear road spring										
— remove and refit	64.20.01 (60.20.01)
— overhaul	64.20.04 (60.20.07)
Rear shock absorber										
— remove and refit	64.30.01 (60.30.02)



1950-1951

1950-1951

1950-1951

1950-1951

1950-1951

1950-1951

1950-1951

1950-1951

1950-1951

1950-1951

1950-1951

1950-1951

1950-1951

1950-1951

1950-1951

1950-1951

1950-1951

1950-1951